


## UPT (URYU Pneumatic Tools )


## US-5 SERIES AIR SCREWDRIVERS














Model	Capacity Screw Size		Free Speed (about)	Weight less Bit (about)		Hex. Size of Bit		Air Inlet Thread (Pipe Tape)	Air Hose Size		Average Air Consumption (about)		Air Pressure	
	in	m/m	r.p.m.	lb.	kg	in.	m/m	in.	in.	m/m	ft³/min	m³/min	MPa	psi
US-5	3/16	5	1,400	2.42	1.10	1/4	6.35	N.P.T. 1/4	1/4	6.4	7.0	0.2	0.4	57
US-5MA	3/16	5	1,400	2.55	1.16	1/4	6.35	N.P.T. 1/4	1/4	6.4	10.7	0.3	0.4	57
US-5PB	3/16	5	1,400	2.86	1.30	1/4	6.35	N.P.T. 1/4	1/4	6.4	7.0	0.2	0.4	57
US-5PMA	3/16	5	1,400	2.97	1.35	1/4	6.35	N.P.T. 1/4	1/4	6.4	10.7	0.3	0.4	57
US-5CA	3/16	5	500	3.08	1.40	1/4	6.35	N.P.T. 1/4	1/4	6.4	10.7	0.3	0.4	57
US-5AA	3/16	5	500	3.08	1.40	1/4	6.35	N.P.T. 1/4	. 1/4	6.4	7.0	0.2	0.4	57
US-50	3/16	5	1,250	1.98	0.90	1/4	6.35	N.P.T. 1/4	1/4	6.4	10.7	0.3	0.4	57

## IMPORTANT!!

Air Pressure: 0.4MPa (57psi) Air Pressure is recommended for the most efficient performance. Too high air pressure will shorten tool's life.

Lubrication: For Air Motor - Supply Turbine Oil properly through Air Inlet or Line Oiler every before and after operation. (For example MOBIL TURBINE OIL #32, SHELL TURBINE OIL #32, and or equivalent.)

For Gears and Bearings - Supply recommended high quality Grease properly (for examples, SHELL ALVANIA NO.2, MOBILPLEX 2, or equivalents). once every three months and when the tool is overhauled.

Over-greasing will cause dull motion or heating. **Dry and Clean Air:** Drain daily, and install Filter at or near the take-off point to prevent trouble from foreign matter.

Air Hose and Joints: Use Air Hose (the shorter, the better), Joints and other fittings of good condition and of proper size to avoid pressure drop.

Genuine Parts: Use only URYU's genuine spare parts for replacement.

REGULAR OVERHAUL - Regular overhaul of once every three months is recommended to keep sufficient performance and to prevent trouble.

Distributed by: