


PARTS LIST OF ANGLE ATTACHMENT

Ref. No.	Parts Name	Parts NO.
Angle Attachment for CL-6000/-6500 (HIOS)	1 - 21	ANGL-Z
Angle Attachment for CL-6000/-6500 (HEX)	1 - 21	ANGLX-Z
Angle Attachment for Alpha-6500/ACL-20 (HIOS)	1 - 21	ANGLA-Z
Angle Attachment for Alpha-6500/ACL-20 (HEX)	1 - 21	ANGLAX-Z
1. Collar Stopper		CL65-0110
2. Joint Shaft Collar		M6-0040
3. Collar Spring		M6-0050
4. Joint Shaft (HIOS)		ANGL-0040
Joint Shaft (HEX)		ANGLX-0040
5. Bearing FLW-676-ZZ		ANGL-0050
6. Bearing FLW-678-ZZ (x3)		ANGL-0060
7. E-Ring E-5		ANGL-0070
8. Drive Shaft (HIOS)		ANGL-0080
Drive Shaft (HEX)		ANGLX-0080
9. Bevel Gear (x2)		ANGL-0090
10. Bevel Gear Lock Pin 2.5x10		SR25X100
11. Gear Box		ANGL-0110
12. Side Plate A 1.6mm		ANGL-0120
13. Side Plate B 1.4mm		ANGL-0130
14. Side Plate Set Screw 2x6 (x4)		SPF20X060
15. Cylinder Fixing Screw (x2)		ANGL-0150
16. Cylinder Fixing Ring		ANGL-0160
17. Cylinder		ANGL-0170
18. Pin		-----
19. Torque Adjusting Nut (CL-Type)		ANGL-0190
Torque Adjusting Nut (Alpha/ACL-Type)		ANGLA-0190
20. Torque Adj. Nut Fixing Screw		CL65-0060 ANGL-0200
21. Bit Lock Ball (HIOS) 2.5φ		BALL-025
Bit Lock Ball (HEX) 2.0φ (x3)		BALL-02

EXPLODED VIEW DRAWING
ANGLE-1



HIOS Inc.
111-6, Akiyama Matsudo City,
Chiba Pref. 271 Japan

(ANGLE-101)