

PARTS LIST OF BL-5000
(H4 HIOS / 5.0 HEX / 6.35 HEX SHANK)

ISSUED : January,2003
Revised : January,2004

PARTS NAME	PARTS NO.	PARTS NAME	PARTS NO.
1 Torque Adjusting nut	BL4-0011	36 Switch Lever Plunger	CL4-0521
2 Torque Adjusting spring holder	BL4-0021	37 Lever Spring	CL4-0510
3 Torque Adjusting spring (purple)	BL4-0051-1.6	38 Name Plate	BL5-0420
4 Clutch Panel	BL4-0060	39 Set Screw 2.6x6	SPP26X060
5 Steel Ball 5.0φ	BALL-05		
6 Clutch Cover	BL4-0171	Circuit Assy 40-47(except46)	BL4-CC
7 Set Screw 2.6x8	STP26X080		
8 Collar Stopper for H4 HIOS	CL4-0090	40 Control Circuit	-----
Collar Stopper for 5.0/6.35HEX	CL4X-0090	41 Push or Lever Change-over Switch	BL4-0370
9 Washer 2.6x9.6x0.5 for H4 HIOS	CL3-0620	42 5 Pin connector	CL4-0580
Washer 8.5x10.5x0.5 for 5.0 HEX	BL4X-0630-5		
Washer 9.1x11.0x0.5 for 6.35 HEX	BL4X-0630	43 Resistor 430Ω	-----
10 Collar Spring for H4 HIOS	BL4-0120	44 Sensor P.C.B. (Lower)	-----
Collar Spring for 5.0 HEX	BL4-0120-5	45 Sensor P.C.B. (Upper)	-----
Collar Spring for 6.35 HEX	BL4X-0120	46 Set Screw M2x5	SPP20X060
11 Joint Shaft Collar for H4 HIOS	BL4-0070	47 Ground Connector	-----
Joint Shaft Collar for 5.0 HEX	BL4X-0070-5	48 Hanger	CL65-0650
Joint Shaft Collar for 6.35 HEX	BL4X-0070		
12 Joint Shaft Cover for H4 HIOS	BL4-3141	49 Free-Up Belt	CL4-0600
Joint Shaft Cover for 5.0/6.35 HEX	BL4X-3141	50 5-Core Cord W/Connectors In Both End	CL4-0611
13 Cap Screw 2.6x6	SC26X060ST		
14 Joint Shaft for H4 HIOS	BL4-0101		
Joint Shaft for 5.0 HEX	BL4X-0101-5		
Joint Shaft for 6.35 HEX	BL4X-0101		
15 Steel Ball 2.0φ	BALL-02		
16 Push Spring	BL4-0130		
17 Joint	BL4-0180		
18 Hexagon Socket Set Screw 2.6x5	SH26X050		
19 Gear Case	BL4-0191		
20 Set Screw 2.6x 5P3	SPC26X050P3		
21 Lower Planet Shaft	BL4-0200		
22 Cam Roller φ4x5.5	CL4-0250		
23 Internal Gear (W/Magnet)	BL4-3210		
24 Lower Floor	BL4-0240		
25 Planet Gear (x8)	VZ10-0300		
26 Upper Planet Cage	VZ10-0330		
27 Center Pin 2x13.8	F9-0260		
28 Bearing	BL4-0310		
29 Set Screw 2.6x 5	STP20X050		
30 Motor Front Panel	BL4-0300		
31 Motor (W/Pinion Gear)	BL4-3340		
32 Body Case A&B	BL4-0540		
33 Set Screw 2.6x12	SPPB26X120		
34 For/Rev Switch Lever	BL4-3360		
35 Switch Lever (W/Magnet)	BL4-3380		