

PARTS LIST OF BL-5000-CCC
(H4 HIOS / H5 HIOS / 5.0 HEX / 6.35 HEX SHANK)

ISSUED : JAN .05th.2009

PARTS NAME	PARTS NO.	PARTS NAME	PARTS NO.
1 Torque Adjusting nut	BL4-0011 504	39 Switch Lever Plunger	BL4-0520 42
2 Steel Ball 1.5φ	BALL-015 8	40 Set Screw 3.5x12	ROHD5F35120N1TP
3 Torque Adjusting spring holder	BL4-0021 168	41 Name Plate	BL5-0420 42
4 Torque Adjusting spring	BL4-0051-1.6 151	42 Lever Spring	CL4-0510 25
5 Clutch Panel	BL4-0060 202	Circuit Assy 43-49(except48)	BL5-CC2-CCC
6 Steel Ball 5.0φ	BALL-05 25		
7 Clutch Cover	BL4-0173 336		
8 Set Screw 2.6x8	SJP26X080N		
9 Collar Stopper for H4 HIOS	CL4-0090 8	43 Control Circuit	
Collar Stopper for H5/5HEX/6.35HEX	CL65-0110 8	44 Push or Lever Change-over Switch	BL4-0370 185
10 Washer 7.6x9.6x0.5 for H4 HIOS	CL3-0620 8	45 5 Pin connector	CL4-0580 504
Washer for H5 HIOS/5HEX	BL65-0130 25		
Washer for 6.35 HEX	BL4X-0630 50		
11 Collar Spring for H4 HIOS	BL4-0120 168	46 Sensor P.C.B. (Lower)	
Collar Spring for H5 HIOS/5HEX	BL65-0120 218	47 Sensor P.C.B. (Upper)	
Collar Spring for 6.35 HEX	BL4X-0120 168	48 Set Screw M2x4	SPC20X040 0
12 Joint Shaft Collar for H4 HIOS	BL4-0070 218	49 Ground Connector	
Joint Shaft Collar for H5 HIOS/5HEX	BL5-0070-H5	50 Hanger	CL65-0651 126
Joint Shaft Collar for 6.35 HEX	BL4X-0070 218	51 Free-Up Belt	CL4-0600 25
13 E-Ring	BL4-0080 13	52 5-Core Cord W/Connectors	CL4C-0611 2100
14 Joint Shaft Cover (W/Magnet) H4/6.35X	BL4X-3141 336	In Both Ends	
Joint Shaft Cover (W/Magnet) H5/5HEX	BL5-3140-H5		
15a Steel Ball 2.0φ H4 HIOS x2pcs	BALL-02 8		
Steel Ball 2.5φ H5 HIOS/5HEX x3pcs	BALL-025 17		
Steel Ball 1.5φ 6.35 HEX x3pcs	BALL-015 8		
15b Steel Ball 2.5φ H4, 6.35HEX	BALL-025 17		
Steel Ball 2.77φ H5/5HEX	BALL-0277		
16 Joint Shaft for H4 HIOS	BL4-0101 504		
Joint Shaft for H5 HIOS/5HEX	BL5-0010		
Joint Shaft for 6.35 HEX	BL4X-0101 504		
17 Push Spring	BL4-0130 34		
18 Joint	BL4-0180 202		
19 Hexagon Socket Set Screw 2.6x3	SH26X030		
20 Gear Case	BL4-0191-FE N/A		
21 Set Screw 2.6x 6	MSPF26060N1GP		
22 Lower Planet Shaft	BL4-0201 440		
23 Cam Roller φ4x5.5	CL4-0250 34		
24 Internal Gear (W/Magnet)	BL4-3210 1680		
25 Lower Floor	BL4-0240 672		
26 Planet Gear (x8)	VZ10-0302 101		
27 Upper Planet Cage	VZ10-0331 252		
28 Center Pin 2x13.8	F9-0260 17		
29 Cup Ring	BL4-0220 630		
30 Bearing	BL4-0311 672		
31 Set Screw 2.0x 5	SJP20X050		
32 Motor Front Panel	BL4-0301 638		
33 Pinion Gear	BL4-0293 N/A		
34 Motor	BL4-0342 12500		
35 Body Case A&B	BL4C-0541		
36 Set Screw 2.6x6	MSPF26060N1GP		
37 For/Rev Switch Lever (W/Magnet)	BL4-3360ESD 122		
38 Switch Lever (W/Magnet)	BL4-3382 168		

(BL-5C-1A)