

PARTS LIST OF BL-7000
(H5 H10S / 6.35 HEX SHANK)

ISSUED: December,2002
Revised: March,2008

PARTS NAME	PARTS NO.	PARTS NAME	PARTS NO.
1 Torque Adjusting nut	BL65-0010	40 Name Plate	BL7-0070
2 Seel Ball 1.5φx3	BALL-015	41 Set Screw 3.5X12	BOHD5F35120NITP
3 Torque Adjusting Spring Holder	BL65-0020	42 Connector Cover	BL65-0471
4 Torque Adjusting spring	BL7-0050	43 Switch Lever	BL65-3490
5 Clutch Panel	BL65-0060	44 Switch Lever Spring	CL65-0610
6 Steel Ball 5.5φ	BALL-055	45 Switch Lever Plunger	CL4-0521
7 Clutch Cover	BL65-0221		
8 Set Screw 3x7	SPP30X070N		
9 Collar Stopper	CL65-0110		
		46 5 Pin connector	CL4-0580
		47 Circuit Assy	BL7-CC1
10 Collar Spring	BL65-0120		
11 Joint Shaft Collar	BL65-0110	48 Set Screw 2x4	SPC20X040
12 C-Ring	BL65-0140		
13 Washer 9.6x11.6x0.5 for 6.35HEX -- 6.35 HEX only	BL65-0130		
14 Push Spring	BL65-0170		
15 Joint Shaft Cover Set H5 H10S	BL65-3210		
Joint Shaft Cover Set 6.35 HEX	BL65X-3210		
16 Steel Ball 2.5φ	BALL-025	49 5-Core Cord W/Connectors In Both Ends	CL65-0660
17 Steel Ball 2.7φ	BALL-0277		
18 Joint Shaft for H5 H10S	BL65-0100	50 Free-Up Belt	CL65-0670
Joint Shaft for 6.35 HEX	BL65X-0100	51 Hanger	CL65-0651
19 Joint Shaft Cover Spring	BL65-0160		
20 Joint	BL65-0200		
21 Hexagon Socket Set Screw 2.6x3	SH26X030		
22 Gear Case	BL65-0230		
23 Set Screw 2.6x6	MSPF26060NIGP		
24 Lower Planet Shaft	BL65-0150		
25 Cam Roller Φ5x7	CL65-0230		
26 Internal Gear (W/Magnet)	BL65-3320		
27 Lower Floor	BL65-0340		
28 Planet Gear	BL65-0331		
29 Upper Planet Cage	BL65-0360		
30 Center Pin 2x13.8	F9-0260		
31 Cup Ring	BL7-0040		
32 Bearing	BL65-0380		
33 Set Screw 3x7	SPP30X070N		
34 Motor Front Panel	BL65-0401		
35 Pinion Gear	BL7-0391		
36 Motor	BL7A-0440		
37 Body Case A&B W/BL65-0471	BL65-0461		
38 Set Screw 3x7	SPP30X070N		
39 For/Rev Switch	BL4-3360ESD		