

PARTS LIST OF VZ-4506PSX (100V)
(Push to Start Type)

ISSUED: February, 2007

PARTS NAME	PARTS NO.	PARTS NAME	PARTS NO.
1 Front Ring	VZ18-0010	43 Joint Pin	VZ18PS-0700U
2 Nut Stopper Ring	VZ18-0022		
3 Torque Adjusting Nut	VZ18-0030	44 Push Rod	VZ18PS-0770
4 Center Pin 2x19.8	DL20-0140	45 Bearing (Included #46)	-----
5 Torque Adjusting Bolt	VZ18-0052	46 Fan	VZ18-3380
6 O-Ring 18dia	M3-0260	47 Motor	VZ45-0390
7 Collar Spring	VZ18X-0070	48 Front Cover	VZ18-0420U
8 Joint Shaft Collar	VZ18X-0080	49 Motor Set Band	VZ18-0410
9 Collar Spring	CL65-0130	50 Motor Bearing	VZ18-0430
10 Stopper Washer (Spring Stopper)	VZ18X-0130	51 Rotor	VZ45-0440
11 Bearing (Included #5)	-----	52 Magnet Case	-----
12 Steel Ball 2.0dia	BALL-02	53 Motor Bearing	CL65-0410
13 Joint Shaft	VZ18X-0120	54 End Cover	VZ18-0470
14 Push Spring	VZ18PS-0591	55 Carbon Brush	VZ18-0480
15 Spring Holder	VZ18-0150	56 Carbon Brush Cap	VZ18-0490
16 Torque Adjusting Spring	VZ45-0160	57 Condensor (Included #47)	-----
17 Thrust Washer Set Ring	VZ45-0170	58 For/Rev Switch	-----
18 Thrust Washer	VZ18-0180	59 Resistor	-----
19A Steel Ball 2.5dia	BALL-025	60 Resistor (Included #47)	-----
19B Steel Ball 2.5dia	BALL-025	61 Sleeve (Included #74)	-----
20 Clutch Panel Spring	VZ30-0200		
21 Clutch Panel Cover	VZ18-0210	62 Earth Cord (Included #74)	-----
22 Clutch Panel	VZ45-0221	63 PCB Assembly (Included Circuit Assy)	-----
23 Cam	VZ45-0240	64 Body Case A&B	VZ18PS-0561
24 Cam Roller 4.5x4.5	VZ40-0250	65 Push Lever	VZ18PS-0570
25 Steel Ball 4.5dia	BALL-045	66 Lever Shaft 2x18.8	VZ18-0580
		67 Push Lever Spring	VZ18PS-0670
26 Ball Guide	VZ18-0262	68 Pivot	VZ18PS-0660
27 Thrust	VZ18-0270	69 Name Plate A	VZ4506PS-0600U
28 Gear Case	VZ40-2280		
		70 Name Plate B	VZ4506-0610
29 Switch Protector	VZ18-0290	71 Set Screw 3x12	STP30X120
30 Limit Switch	CL4-0230		
31 Set Screw 3x6	STP30X060	Circuit Assmbly 30,58,59,63	VZ18-3551
32 Ground Connector	VZ18-0730U	For/Rev Switch Assembly 58,59	VZ18-3521
33 Center Pin 2x71.9	VZ18PS-0690	72 Hanger	CL65-0651
34 Lower Planet Cage	VZ4506-0360	73 End Ring	VZ18-0641
35 Planet Gear	VZ4506-0370	74 AC Cord W/Earth	VZ18-0651
36 Thrust Washer	CL4-0290		
37 Plate B	A65A-0680		
38 Upper Planet Cage	VZ4506-0400		
39 Planet Gear	VZ4506-0370		
40 Pinion Gear	VZ3007-0410		
41 Grease Seal	ACL20-0351		
42 OV-Ring	VZ18-0350		