


AG-50&50L ANGLE GRINDERS

EXPLODED VIEW



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
# 1	536-025-2	Casing	1	#23	975-799-0	Adjusting Spacer (27×23×t)	1	#43	981-207-0	Ball (Black) (9/32)	1
# 2	505-285-2	Rear Plate	1	#24	975-807-0	Adjusting Spacer (28×25×t)	1	#44	990-908-0	O-Ring (SNS10)	1
# 3	505-291-1	Rear Plate Spacer	1	#25	978-097-0	Snap Ring (9.5×0.8)	1	#45	990-919-0	O-Ring (SNS22)	1
# 4	505-286-1	Cylinder	1	#26	978-219-0	Snap Ring (22×1.2)	1	Parts for AG-50L			
# 5	536-287-2	Rotor	1	#27	982-015-0	Ball Bearing (608)	1	#46	504-014-4	Handle Body	1
# 6	505-288-1	Blade	4	#28	982-021-0	Ball Bearing (626)	1	#47	601-108-1	Valve Plug	1
# 7	536-289-2	Front Plate	1	#29	982-101-0	Ball Bearing (6001)	1	#48	500-914-7	Self-Locking Valve Lever Assy.	1
# 8	536-420-2	Driving Gear.	1	#30	988-340-0	Needle Roller Bearing (TLAM69)	1	#49	973-020-0	Roll Pin (2×20)	1
# 9	536-430-2	Driven Gear	1	#31	990-914-0	O-Ring (SNS16)	1	#50	970-222-0	Pin (H) (3×22)	1
#10	536-390-2	Wheel Spindle	1	#32	993-023-0	Felt-Ring (15×22×3)	1	#51	976-114-0	Spring (6×18×0.55)	1
#11	536-065-2	Casing Front Cover	1	#33	536-924-2	Name Plate	1	#52	981-207-0	Ball (Black) (9/32)	1
#12	536-393-2	Wheel Holder Flange	1	#34	930-205-0	Driver Rivet (No.0×2.6)	2	#53	990-923-0	O-Ring (SNS26)	1
#13	536-394-2	Wheel Nut Flange	1	Parts for AG-50				#54	990-904-0	O-Ring (SNS6)	1
#14	536-770-2	Wheel Guard	1	#35	507-014-9	Handle Body	1	Accessories			
#15	945-943-0	Hexagon Round Head Bolt (M4×8)	2	#36	507-015-9	Valve Handle	1	#55	940-114-0	Air Hose NIPPLE (NPT1/4×3/8)	1
#16	961-010-0	Flat Washer(4)	2	#37	621-164-0	Spring Spacer	1	#56	936-521-0	Spanner (21)	1
#17	966-022-0	Plug (1/8)	1	#38	952-206-0	Allen Head Dog Point Screw (M5×6)	1	#57	939-104-0	Amen Wrench (5mm)	1
#18	973-006-0	Roll Pin (2×6)	1	#39	970-211-0	Pin (H)(3×12)	1	#58	942-114-0	Connecting Screw (1/4×NPT1/4)	1
#19	974-005-0	Key (3×6)	1	#40	976-528-0	Spring (22.5×15×1.2)	1				
#20	975-785-0	Adjusting Spacer (27×25×t)	1	#41	977-102-0	Cone Spring (6×9×8×0.6)	1				
#21	975-212-0	Spacer (27×23×0.5)	1	#42	979-005-0	Inner Snap Ring (12)	1				
#22	975-218-0	Spacer (28×25×0.5)	1								

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

Jan 2012

OKA-515-11-10-05-1002