


UAG-50SBL-120T

EXPLODED VIEW



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
# 1	567-014-5	Valve Body	1	# 26	597-770-7	Wheel Guard	1	# 49	977-230-0	Cone Spring (9.6×13×9)	1
# 2	590-015-4	Valve Handle	1	# 27	596-720-6	Dead Handle	1	# 50	978-159-0	Snap Ring (16×1)	1
# 3	573-019-5	Valve Cover	1	# 28	597-762-4	Exhaust Hose Connector	1	# 51	978-305-0	Snap Ring (30×1)	1
# 4	597-736-4	Valve Body Nut	1	# 30	946-118-0	Hexagon Head Bolt (M5×18)	1	# 52	979-010-0	Inner Snap Ring (17)	1
# 5	597-914-4	Self-Locking Valve Lever Assembly	1	# 31	948-533-0	Allen Flush Bolt(M5×25)	1	# 53	979-103-0	Outer Snap Ring (6)	1
# 6	597-012-4	Valve Body Connector	1	# 32	952-212-0	Allen Head Dog	1	# 54	981-212-0	Ball (7/16)	1
# 7	596-170-6	Governor Valve	1			Point Screw (M5×12)	1	# 55	982-013-0	Ball Bearing (606)	1
# 8	596-181-6	Governor Cage	1	# 33	960-036-0	Hexagon Nut (1-M5)	1	# 56	982-054-0	Ball Bearing (629Z)	2
# 9	596-176-6	Governor Spindle	1	# 34	961-014-0	Flat Washer (8)	1	# 57	982-242-0	Ball Bearing (6202Z)	1
# 10	596-183-6	Governor Weight	2	# 35	962-008-0	Spring Washer (2-5S)	1	# 58	990-913-0	O-ring (SNS-15)	2
# 11	597-025-4	Casing	1	# 36	962-011-0	Spring Washer (2-8S)	1	# 59	990-920-0	O-ring (SNS-25)	1
# 12	596-291-6	Rear Plate Spacer	1	# 37	965-040-0	Heli-Sert (M8×1D)	1	# 60	990-937-0	O-ring (SNS-46)	1
# 13	596-285-6	Rear Plate	1	# 38	966-100-0	Allen Head Plug (1/8)	1	# 61	993-913-0	Felt Ring (22×32×4)	1
# 14	596-286-6	Cylinder	1	# 39	970-147-0	Pin (2.5×5)	1	Accessories			
# 15	596-287-6	Rotor	1	# 40	970-328-0	Pin (4×27)	1	# 62	936-000-0	Spanner (19×4×120)	1
# 16	596-288-6	Blade	4	# 41	973-110-0	Roll Pin (3×10)	1	# 63	939-007-0	Allen Wrench (6)	1
# 17	596-289-7	Front Plate	1	# 42	973-118-0	Roll Pin (3×18)	2	# 64	942-123-0	Connecting Screw (3/8×NPT3/8)	1
# 18	596-420-6	Driving Gear	1	# 43	973-126-0	Roll Pin (3×26)	1	597-900-5 Combination Hose Assembly			
# 19	596-430-6	Driven Gear	1	# 44	974-008-0	Key (3×8)	1	# 77	935-420-0	Duct Hose (26.5×1.8)	1
# 20	596-390-3	Wheel Spindle	1	# 45	975-268-0	Spacer (35×31×0.5)	1	# 78	934-533-0	Leader Hose Assembly	1
# 21	596-013-6	Casing Rear Cover	1	# 46	975-739-0	Adjusting Spacer (12×8.6×t)	1				
# 22	596-065-6	Casing Front Cover	1			Adjusting Spacer (35×31×t)	2				
# 23	597-393-7	Wheel Holder Flange	1	# 47	975-835-0	Adjusting Spacer (35×31×t)	2				
# 24	597-394-3	Wheel Nut Flange	1	# 48	976-282-0	Spring (11.5×11 (1.4))	1				
# 25	597-021-4	Exhaust Cover	1								

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan

URYU SEISAKU, LTD.

Osaka, Japan

OKA-404-93-12-09-200