


UA70MC OIL-PULSE WRENCH

EXPLODED VIEW



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
# 1	131-025-7	Handle	1	#31	990-912-0	O-Ring (SNS-14)	1	#61	970-202-0	Pin (H)(3×4.5)	2
# 2	147-100-3	Valve	1	#32	990-914-0	O-Ring (SNS-16)	1	#62	970-204-0	Pin (H)(3×6)	1
# 3	147-104-2	Valve Rod	1	#33	990-916-0	O-Ring (SNS-18)	1	#63	969-449-0	Pin (G)(3×6)	2
# 4	147-107-2	Valve Lever	1	#34	143-285-8	Rear Plate	1	#64	976-788-0	Spring (3.5×25)WPC	2
# 5	851-306-1	Reverse Valve	1	#35	143-286-8	Cylinder	1	#65	976-755-0	Spring (3×13.3)	1
# 6	851-359-1	Reverse Valve Bushing	1	#36	143-287-8	Rotor	1	#66	990-923-0	O-Ring (SNS-26)	1
# 7	173-212-0	Reverse Lever	1	#37	147-288-6	Blade	9	#67	990-334-0	O-Ring (JW1530-24)	1
# 8	851-307-1	Reverse Valve Spacer	1	#38	143-289-8	Front Plate	1	#68	990-900-0	O-Ring (SNS-2)	2
# 9	147-091-2	Air Inlet Bushing	1	#39	143-036-8	Hammer Casing Connector	1	#69	992-020-0	SU Ring (Q12)	1
#10	147-780-3	Exhaust Stack	1	#40	971-102-0	Pin (2×3.8)	1	#70	131-867-7	Front Casing Packing	1
#11	147-042-2	Silencer	1	#41	973-008-0	Roll Pin (2×8)	2	#71	851-698-1	Sensor Casing Assembly (S06S)	1
#12	147-835-3	Filter (K200)	1	#42	981-045-0	Ball (1.5)	8	#72	945-117-0	Allen Head Bolt (M5×16)	4
#13	851-301-1	Connector	1	#43	982-014-0	Ball Bearing (607)	1	#73	904-090-0	Extension Bar (3/8×45)	1
#14	851-302-1	Cap	1	#44	982-902-0	Ball Bearing (6901)	1	#74	953-104-0	Allen Head Screw (M4×4)	1
#15	851-303-1	Stopper	2	#45	17E-901-0	Rear Liner Plate	1	#75	971-214-0	Pin (3×14)	1
#16	131-395-8	Outer Ring	1	#46	18E-902-3	Liner	1	#76	990-011-0	O-Ring (P-12)	1
#17	174-790-0	Suspension Ring	1	#47	851-308-1	Anvil	1	#77	930-205-0	Driver Rivet	2
#18	17D-842-3	Handle Cover	1	#48	147-440-6	Driving Blade	2	#78	909-918-0	Double-Row Socket	1
#19	131-840-7	Casing Protector	1	#49	147-974-6	Roller (2.5×28)	2	#79	911-012-0	Connector Cover	1
#20	948-423-0	Allen Flush Head Screw (M3×6)	2	#50	944-203-0	Back-up Ring (3.1×5×1)	1	#80	17E-924-0	Metal Tag (UA70MC)	1
#21	952-008-0	Allen Head Screw (M3×8)	1	#51	18E-904-3	Front Liner Plate	1	ACCESSORIES			
#22	965-011-0	Heli-Sert (M5×1.5D)	4	#52	17E-905-0	Liner Casing	1	#88	910-258-0	Joint Cable Assembly	1
#23	971-130-0	Pin (2×30)	1	#53	147-906-6	Liner Casing Cover	1	#89	939-091-0	Allen Wrench (1.5)	1
#24	973-014-0	Roll Pin (2×14)	1	#54	174-907-2	Relief Valve Spindle	1	#90	940-114-0	Air Hose Nipple (NPT1/4×3/8)	1
#25	976-006-0	Spring (3×5)	1	#55	17E-970-0	Relief Valve	1	#92	909-749-0	Solenoid Valve Assembly	1
#26	976-457-0	Spring (7×12)	1	#56	18F-274-2	Pressure Valve Spring Collar	1	#93	910-263-0	Sensor Cable Assembly (3F5)	1
#27	979-405-0	Outer Snap Ring (E2.5)	1	#57	080-276-6	Pressure Valve Body	1	#94	910-633-0	Connector Cover	1
#28	981-002-0	Ball (1/8)	1	#58	194-742-0	Oil Plug	1				
#29	990-306-0	O-Ring (APR-569-004)	1	#59	944-013-0	Back-up Ring (P-12)	1				
#30	990-929-0	O-Ring (SNS-36)	2	#60	970-013-0	Pin (H)(1.5×4)	1				

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

Jun 2012

OKA-545-12-06-20-0501