


UX-612S(D) OIL-PULSE WRENCHES

EXPLODED VIEW



PARTS LIST

Index. No.	Code No.	Parts Name	Quantity	Index. No.	Code No.	Parts Name	Quantity	Index. No.	Code No.	Parts Name	Quantity
# 1	179-025-0	Casing	1	# 31	978-282-0	Snap Ring (28×1.0)	1	PARTS FOR UX-612S			
# 2	180-210-2	Reverse Valve	1	# 32	970-135-0	Pin (H) (2.45×11)	2	# 21	891-316-1	Anvil(OP-P) Assy.	1
# 3	180-100-2	Valve	1	# 33	965-073-0	Heli-Sert (UNF5/8×N6)	1	# 68	891-300-1	Socket Retainer Pin Assy	1
# 4	180-210-2	Reverse Valve	1	# 34	966-099-0	Allen Head Plug (NPT1/16)	1	PARTS FOR UX-612SD			
# 5	500-107-1	Valve Lever	1	# 36	970-130-0	Pin (H) (2.45×4.5)	2	# 73	178-350-0	Driver Anvil	1
# 6	180-091-6	Air Inlet Bushing	1	# 37	970-326-0	Pin (H) (4×25)	1	# 74	011-351-1	Bit Sleeve	1
# 7	194-780-4	Exhaust Stack	1	# 38	973-022-0	Roll Pin (2×22)	1	# 75	011-352-1	Bit Spacer	1
# 7-1	190-781-6	Exhaust Stack Bushing	1	# 39	971-163-0	Pin (2.5×23)	1	# 76	976-327-0	Spring (13.5×11)	1
# 8	194-042-4	Silencer	1	# 39-1	973-005-0	Roll Pin (2×5)	1	# 77	978-117-0	Snap Ring (11.7×1.0)	1
# 9	611-780-7	Filter	1	# 41	973-006-0	Roll Pin (2×6)	1	# 78	981-002-0	Ball(1/8)	1
# 10	180-285-2	Rear Plate	1	# 42	973-008-0	Roll Pin (2×8)	2	ACCESSORIES			
# 11	180-286-2	Cylinder	1	# 43	973-124-0	Roll Pin (3×24)	1	# 28	940-114-0	Air Hose Nipple (NPT1/4×3/8)	1
# 12	196-287-4	Rotor	1	# 45	975-598-0	Round Plate(18×1)	1	# 79	900-028-0	Hexagon Socket (10×19)	1
# 13	150-288-9	Rotor Blade (PC)	7	# 46	976-792-0	Spring(3.5×21)(0.45)WPC	2	# 80	939-105-0	Allen Wrench (4MM)	1
# 14	182-289-2	Front Plate	1	# 47	976-147-0	Spring (7×12)	1	# 81	939-091-0	Allen Wrench (1.5) (80×20)	1
# 15	177-036-5	Hammer Casing Connector	1	# 48	979-318-0	Inner Snap Ring (IRTW-18)	1	# 82	916-810-0	(+) Double Bit (No.2×75)	1
# 16	178-439-8	Front Casing	1	# 50	981-208-0	Ball (5/16)	1	# 83	971-990-0	Pin (3×16.5)	1
# 17	190-328-6	Anvil Bushing	1	# 51	982-401-0	Ball Bearing (EE-2)	1	# 84	990-290-0	O-Ring (JW12)	1
# 18	178-905-9	Liner Casing	1	# 52	982-402-0	Ball Bearing (EE-3)	1				
# 19	196-901-4	Rear Liner Plate	1	# 53	990-322-0	O-Ring (ARP-568-107)	1				
# 20	190-902-6	Liner	1	# 54	990-008-0	O-Ring (P10)	1				
# 22	190-440-6	Driving Blade	2	# 55	990-014-0	O-Ring (P14)	2				
# 23	178-904-8	Front Liner Plate	1	# 56	990-320-0	O-Ring (ARP-568-003)	2				
# 24	174-907-8	Relief Valve Spindle	1	# 57	178-319-8	Anvil(OP-O)	1				
# 25	190-906-6	Liner Casing Cover	1	# 58	990-329-0	O-Ring (JW1530-19)	1				
# 26	178-742-0	Oil Plug	1	# 60	990-914-0	O-Ring (SNS-16)	2				
# 27	010-790-1	Suspension Ring	1	# 61	995-512-0	Teflon Seal (P12)	1				
# 29	944-002-0	Supporting Ring (2.6×4.5×1)	2	# 62	981-045-0	Ball(1.5)	1				
# 30	178-327-9	Anvil Front Spacer	1								

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

OKA-356-04-06-14-2006