


UX-T900 TORQUE CONTROL OIL-PULSE WRENCH

EXPLODED VIEW



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
# 1	151-012-9	Head Cover	1	#33	194-440-3	Driving Blade	2	#63	976-794-0	Spring (3.8×33) (0.5) WPC	2
# 2	175-253-7	Shut-Off Valve Bushing	1	#34	168-904-4	Front Liner Plate	1	#64	976-274-0	Spring (5.2×15)	1
# 3	175-254-7	Shut-Off Valve	1	#35	194-905-3	Liner Casing	1	#65	976-275-0	Spring (6.7×12)	1
# 4	175-927-9	Shut-Off Valve Cover	1	#36	194-906-3	Liner Casing Setter	1	#66	977-013-0	Cone Spring (3.2×3.8×7)(0.55)	1
# 5	175-968-9	Pilot Valve Retainer	1	#37	175-907-9	Relief Valve Spindle	1	#67	977-175-0	Cone Spring (7.5×10.3×22)	1
# 6	175-019-9	Valve Cover	1	#38	168-970-4	Relief Valve	1	#68	979-318-0	Inner Snap Ring (IRTW-18)	1
# 7	168-025-4	Handle	1	#39	194-742-3	Oil Plug	1	#69	981-002-0	Ball (1/8)	1
# 8	188-100-1	Valve	1	#39-1	944-003-0	Supporting Ring (3.0×5.0×1)	1	#70	981-006-0	Ball (1/4)	1
# 9	063-102-3	Valve Bushing	1	#40	151-853-9	Head Cover Packing	1	#71	981-208-0	Ball (5/16) (BLACK)	1
#10	193-104-6	Valve Rod	1	#41	194-867-3	Front Casing Packing	1	#72	982-403-0	Ball Bearing (EE-4)	1
#11	187-107-1	Throttle Trigger	1	#42	004-790-2	Suspension Ring	1	#73	982-950-0	Ball Bearing (16002)	1
#12	185-091-7	Air Inlet Bushing	1	#43	944-205-0	Supporting Ring (5.1×7×1)	1	#74	990-004-0	O-Ring (P6)	1
#13	187-210-1	Reverse Valve	1	#44	944-215-0	Supporting Ring (16×19.9×1.5)	1	#75	990-205-0	O-Ring (JW1516-5)	1
#14	185-211-1	Reverse Valve Bushing	1	#45	945-117-0	Allen Head Bolt (M5×16)	8	#76	990-320-0	O-Ring (APR568-003)	1
#15	023-212-4	Reverse Lever	1	#46	952-108-0	Allen Head Dog Point Screw (M4×8)	1	#77	990-901-0	O-Ring (SNS-3)	1
#16	054-220-1	Reverse Lever Notch	1	#47	965-011-0	Heli-Sert (M5×1.5D)	8	#78	990-907-0	O-Ring (SNS-9)	1
#17	187-222-1	Reverse Valve Setter	1	#48	965-073-0	Heli-Sert (UNF5/8) (N6)	1	#79	990-914-0	O-Ring (SNS-16)	4
#18	194-780-4	Exhaust Stack	1	#49	966-100-0	Allen Head Plug (1/8)	1	#80	990-607-0	O-Ring (34×2.3)	1
#19	194-042-4	Silencer	1	#50	969-450-0	Pin (G) (3×8)	1	#81	990-338-0	O-Ring (JW1530-28)	1
#20	174-780-3	Filter	1	#51	970-093-0	Pin (H) (2×6)	1	#82	990-970-0	O-Ring (SNS-2)(NOK)	1
#21	194-285-3	Rear Plate	1	#52	970-206-0	Pin (H) (3×8)	1	#83	990-972-0	O-Ring (SNS-4)(NOK)	1
#22	194-286-3	Cylinder	1	#53	971-163-0	Pin (2.5×23)	4	#84	995-516-0	Teflon Seal (P16GC)	1
#23	168-287-4	Rotor	1	#54	973-016-0	Roll Pin (2×16)	1	#85	891-304-1	Socket Pin Assembly (1/2)	1
#24	168-288-6	Rotor Blade (PC)	6	#55	973-066-0	Roll Pin (2.5×6)	1	#82-1	990-970-0	O-Ring (SNS-2)(NOK)	1
#25	194-289-3	Front Plate	1	#56	973-108-0	Roll Pin (3×8)	2	ACCESSORIES			
#26	194-439-3	Front Casing	1	#57	973-114-0	Roll Pin (3×14)	2	#87	940-114-0	Air Hose Nipple (NPT1/4×3/8)	1
#27	188-328-2	Anvil Bushing	1	#58	973-340-0	Roll Pin (6×10)	2	#88	939-104-0	Allen Wrench (5MM)	1
#28	168-901-4	Rear Liner Plate	1	#59	975-598-0	Round Plate (18×1)	1	#89	939-109-0	Allen Wrench (2MM)(64-64)	1
#29	168-902-4	Liner	1	#60	975-780-0	Adjusting Spacer (21×13×T)	1				
#30	175-546-9	Piston	1	#61	976-025-0	Spring (3×8.5)	1				
#31	168-130-4	Piston Rod	1								
#32	891-311-1	Anvil (OP-P) Assy	1								

When ordering spare parts, please specify tool type, code number and part name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

Parts for UX-TL900

#90 976-276-0 Spring(6.7X12 (0.7) SUS
#91 977-014-0 Cone Spring (3.2X3.8X7.2)(0.5)

OKA-371-01-09-20-2005