


EXPLODED VIEW OF BRH-1USV



BRH-1USV(R)

Index. No.	Code No.	Parts Name	Quantity	
1	711-011-7	HANDLE	1	*
2	553-103-1	VALVE BUSHING	1	*
3	201-108-1	VALVE PLUG	1	*
4	500-107-1	VALVE LEVER	1	*
5	180-091-6	AIR INLET BUSHING	1	*
6	711-740-7	PIPE	1	
7	711-805-7	O-RING COVER	1	
8	235-885-0	SILENCER	1	*
9	711-025-7	CASING	1	
10	711-767-7	CASING COVER	1	
11	705-195-1	MAIN VALVE	1	**
12	705-196-1	VALVE BOX	1	**
13	705-197-1	VALVE BOX COVER	1	**
14	705-286-1	CYLINDER	1	***/*
15	705-546-1	PISTON	1	
16	705-567-1	BUSHING(R)	1	***
17	710-782-8	EXHAUST DEFLECTOR	1	

17-1	010-790-1	SUSPENSION RING	1	
21	970-321-0	PIN (H)(4X21)	1	*
22	973-124-0	ROLL PIN (3X24)	1	*
23	977-154-0	CONE SPRING (7X7.5X17)	1	*
24	979-015-0	INNER SNAP RING (22)	1	
25	979-127-0	OUTER SNAP RING (30)	1	
26	980-005-0	ROUND HEAD NOTCH (2.5)	1	**
27	980-006-0	ROUND HEAD NOTCH (3)	1	**
28	980-010-0	FLAT HEAD NOTCH (S)(3)	1	
29	981-030-0	BALL (3/8)	1	*
30	990-008-0	O-RING (P10)	2	
31	990-027-0	O-RING (P28)	1	
32	990-045-0	O-RING (P48-A)	2	
33	990-047-0	O-RING (P50-A)	2	
34	990-918-0	O-RING (SNS-20)	1	
35	990-934-0	O-RING (SNS-44)	1	
36	990-989-0	O-RING (SNS-60)	1	
*	711-982-7	HANDLE ASSEMBLY		
**	705-892-1	MAIN VALVE ASSEMBLY		
***	705-880-1	CYLINDER ASSEMBLY (R)		

BRH-1USV(H)

40	786-567-1	BUSHING (H)	1	****
****	786-880-1	CYLINDER ASSEMBLY (H)		

Standard Accessories

18	705-810-1	RETAINER SPRING (SMALL)	1	
19	705-813-1	RETAINER SPRING (FLAT)	1	
41	940-116-0	AIR HOSE NIPPLE (NPT 1/4X3/8)	1	
37	920-021-0	ROUND HEAD RIVET SET (3.0)	1	
38	920-800-0	FLAT HEAD RIVET SET (LARGE)	1	