


US-LT40(B)-08(15)C SCREW DRIVER

EXPLODED VIEW



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
# 1	461-025-6	Casing	1	#43	469-420-5	Driving Gear	1	Parts for US-LT40(B)-08C			
# 2	480-091-8	Air Inlet Bushing	1	#44	469-431-6	Driven Gear Spindle	1	#78	472-460-7	Rotor Gear	1
# 3	461-097-6	Air Inlet Connector	1	#44-1	970-108-0	Pin (H) (2×26.8A)	1	#79	472-480-7	First Gear Cage	1
# 4	259-100-0	Valve	1	#45	469-488-5	Angle Head Casing Cover	1	#80	472-470-7	First Planet Gear	3
# 5	461-102-6	Valve Bushing	1	#46	010-790-1	Suspension Ring	1	#81	472-485-7	Second Gear Cage	1
# 6	553-103-1	Valve Rod Bushing	1	#47	944-019-0	Back-up Ring (P19)	1	#82	472-471-7	Second Planet Gear	3
# 8	463-104-7	Valve Rod	1	#48	970-092-0	Pin (H) (2×5.5)	1	#83	976-515-0	Spring (22.7×28) (2.6) (STANDARD)	1
# 9	444-106-8	Valve Rod Cap	1	#49	970-105-0	Pin (H) (2×24)	1	#84	976-516-0	Spring (22.1×28) (2.3) (WEAK)	1
#10	700-107-1	Valve Lever	1	#50	972-089-0	Roller Pin (3×8)	6	#85	976-517-0	Spring (21.5×31) (2.0) (WEAKER)	1
#11	461-114-6	Valve Pin	1	#51	969-470-0	Pin (2×8)	1	Parts for US-LT40(B)-15C			
#12	259-254-0	Shut-off Valve	1	#52	973-006-0	Roll Pin (2×6)	1	#86	472-460-5	Rotor Gear	1
#13	461-567-6	Bushing	1	#53	973-010-0	Roll Pin (2×10)	2	#87	472-480-5	First Gear Cage	1
#14	996-424-0	Packing (16×9×2)	1	#54	973-118-0	Roll Pin (3×18)	1	#88	472-470-5	First Planet Gear	6
#15	893-057-1	Reverse Valve(Lock)	1	#55	975-106-0	Spacer (18.5×11×1)	1	#89	472-485-5	Second Gear Cage	1
#16	472-211-7	Reverse Valve Bushing	1	#56	975-590-0	Round Plate (6.3×1)	1	#90	976-516-0	Spring (22.1×28) (2.3) (STANDARD)	1
#17	472-782-7	Exhaust Deflector	1	#57	975-768-0	Adjusting Spacer (19×16.2×T)	1	#91	976-515-0	Spring (22.7×28) (2.6) (STRONG)	1
#18	472-835-7	Filter	2	#58	975-771-0	Adjusting Spacer (20×18×T)	1	#92	976-517-0	Spring (21.5×31) (2.0) (WEAK)	1
#19	472-285-7	Rear Plate	1	#59	976-058-0	Spring (4.5×11) (0.4)	1	Parts for US-LT40B			
#20	472-286-7	Cylinder	1	#60	976-147-0	Spring (7×12) (0.6)	1	#93	469-430-5	Driven Gear	1
#21	472-287-7	Rotor	1	#61	977-071-0	Cone Spring (5.5×11.5×15)	1	#94	430-356-1	Bit Band	1
#22	472-288-0	Blade (PC)	5	#62	977-155-0	Cone Spring (7×10×35)	1	#95	981-002-0	Ball (1/8)	1
#23	472-289-7	Front Plate	1	#63	979-326-0	Inner Snap Ring (IRTW-26)	1	Parts for US-LT40			
#24	461-291-6	Rear Plate Spacer	1	#64	979-190-0	Outer Snap Ring (22)	1	#96	469-430-8	Driven Gear	1
#25	472-029-7	Gear Casing	1	#65	979-351-0	Inner Snap Ring (ISTW-10)	1	#98	981-002-0	Ball (1/8)	1
#26	496-483-1	Gear Casing Spacer	1	#66	981-000-0	Ball (1/16)	24	#99	976-346-0	Spring (2.9×6.35)	1
#27	472-807-7	Spacer	1	#67	981-001-0	Ball (3/32)	2	Accessories			
#28	461-369-8	Clutch Casing	1	#68	981-004-0	Ball (3/16)	5	#100	916-510-0	(+) Double Bit (No.2×23) (6.35)	1
#29	461-344-6	Cam Retainer	1	#69	982-063-0	Ball Bearing (606ZZ)	1	#101	939-402-0	Manual Driver (No.2)	1
#30	472-346-5	Cam	1	#70	982-035-0	Ball Bearing (698)	1	#104	940-113-0	Air Hose Nipple (NPT 1/4×1/4)1	1
#31	472-319-7	Anvil	1	#71	982-100-0	Ball Bearing (6000)	1				
#32	472-375-7	Cam Ring	1	#72	987-039-0	Miniature Ball Bearing (R1560ZZ)	1				
#33	472-379-8	Retainer	1	#73	988-090-0	Needle Roller Bearing (B-24)	1				
#34	471-318-5	Pilot Pin	1	#74	988-394-0	Needle Roller Bearing (FJ-1210)	1				
#35	471-764-7	Notch Pin	1	#75	988-689-0	Needle Roller Bearing (RLM-1010)	1				
#36	472-562-8	Spring Holder	1	#76	990-911-0	O-Ring (SNS-12)	1				
#37	472-257-8	Regulating Screw	1	#77	990-923-0	O-Ring (SNS-26)	1				
#38	472-370-7	Clutch Casing Sleeve	1								
#39	471-670-7	Band	1								
#40	469-441-7	Angle Casing	1								
#41	469-081-6	Locking Nut	1								
#42	469-807-5	Spacer	1								

When ordering spare parts, please specify tool type, code number and part name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

OKA-331-03-06-10-2006